


Product Code:
A-NUC105-M1B / A-NUC63-M1B

140300803_01_V2

1		2		3		4		x4
5		6		7		8		x4
9		10		11		12		
13		14		15				
For A-NUC105-M1B								
16		17						
For A-NUC63-M1B								
18		19		20				
				x2	for i3/i5			x4

Internal Cable Connectors



CN-T
根據圖示說明,將機箱線材插在相對應的端子上。
注意: 如果在主板上沒看到相對應的端子,請參考主板之使用說明。
如果線材接錯,有可能造成主板損壞。

Power switch

Hard drive LED


Power LED

SATA SATA


USB 2.0 ports

USB 3.0 ports

Rear Panel Layout




A Aluminium heatsink for heat transfer
B Front panel PCB
C M/B mounting standoffs
D 2.5" HDD / SSD mounting holes





For A-NUC105-M1B only

Fan Simulator Module Installation



1



A detailed line drawing of the rear panel of the device. It features a variety of ports and connectors: two RJ45 ports on the left, two USB-A ports in the center, a single USB-C port to the right of the USB-A ports, a 3.5mm audio jack, and several other specialized ports including FireWire, eSATA, and a DVI port. There are also several screws for mounting and a small circular indicator light.










Diagram 18 shows the back of the printer with a power cord being plugged into a power jack. An inset shows a close-up of the power cord's connector.

