

# **Smart Card Reader Driver update Tutorial**



**Date: 2023/01/16  
(Version: 1.0)**

**This Driver only supports Windows 10 X64 System**


# Step 1. Checking the currently driver version

Before update the driver, checking the currently driver version

- Open the Device manager and find the smart card reader device
- Right click to check the properties of the device





c. Choose Driver page to check the currently driver version as below photo:




## Step 2. Update the Driver for the device

► **Note: This Driver only supports Windows 10 x64 system**

a. Decompress the folder with the driver (there're four file in the folder)



b. Open the Device manager and choose “Update driver” option



### c. Choose “Browse my computer for drivers”



 Update Drivers - Microsoft Usbccid Smartcard Reader (WUDF)

How do you want to search for drivers?

→ Search automatically for drivers


Windows will search your computer for the best available driver and install it on your device.

→ Browse my computer for drivers


Locate and install a driver manually.

Cancel

d. Select the folder that included the driver file




e. Update the driver until system show the window as below:





f. Check the driver version after update the driver

Alcorlink USB Smart Card Reader Properties



g. Plug the smart card and check if the function is work properly

